# Doors

Index

FRONT CHANNEL

GLASS RUN CHANNEL

POWER DOOR MIRROR

GLASS
Adjustment, page 14-10

REGULATORS

CENTER CHANNEL

OUTER
MOLDING

MANUAL DOOR MIRROR

POWER WINDOW
MOTOR

DOOR HINGE

DOOR
Disassembly, page 14-4
Assembly, page 14-10
Adjustment, page 14-12

REGULATOR
HANDLE

OUTSIDE DOOR
HANDLE

INSIDE DOOR
HANDLE

DETENT ROD

INSIDE HANDLE
TRIM PLATE

LATCH ASSMBLY

STRIKER

LOWER WEATHERSTRIP

LOCK
CYLINDER

POWER WINDOW
SWITCH

DOOR LOCK
ACTUATOR

DOOR PANEL
BRACKET

DOOR INNER
WEATHERSTRIP

SPEAKER COVER

WEATHERSTRIP

DOOR PANEL

PLASTIC COVER

COURTESY LIGHT

Rear:

POWER WINDOW
REGULATOR

GLASS
Adjustment, page 14-11

GLASS RUN CHANNEL

CENTER CHANNEL

OUTSIDE DOOR
HANDLE

REGULATOR

OUTER MOLDING

POWER WINDOW
MOTOR

REAR CHANNEL

REGULATOR HANDLE

OUTSIDE COVER
PANEL

LOCK CRANK

INSIDE DOOR
HANDLE

DETENT
ROD

INSIDE COVER
PANEL

INSIDE HANDLE
TRIM PLATE

LATCH
ASSEMBLY

DOOR HINGE

DOOR
Disassembly, page 14-7
Assembly, page 14-10
Adjustment, page 14-12

STRIKER

DOOR INNER WEATHERSTRIP

POWER WINDOW
SWITCH

DOOR LOCK ACTUATOR

DOOR PANEL
BRACKETS

COURTESY LIGHT

PLASTIC COVER

DOOR PANEL

WEATHERSTRIP

14-3